

ActiveAhead Sense Circular Holder Datasheet

Helvar

Sensor Accessory Series



- Accessory for mounting the Active+ Sense and ActiveAhead Sense sensor to the ceiling
- Easy installation
- Suitable for flush mounting
- Sturdy structure, internal strain relief
- Available in white [5692]

Package Contents


One ActiveAhead Sense Circular holder accessory kit consists of the following parts:

- 1 x Sensor holder
- 1 x Strain relief part
- 2 x Locking springs

Note: Circular sensor holders are packed in bags of ten sets which also contains 1 x Installation Guide.

Dimensions (mm)

Dimension tolerance $\pm 0,2$ mm



Materials and Conditions

Material Specifications

Material Type	Polycarbonate
Fire Retardant	Yes
UV Protected	Yes
Colour	White, RAL 9016

Glow-wire flammability test (GWFI) 650°C (IEC 60695-2-12)

Operating and Storage Conditions

Ambient temperature range: 0 °C to +40 °C
Storage temperature range: -40 °C to +80 °C



Note: Holder cannot be used to provide higher classification against ingress of dust or moisture.

Conformity and Standards

Luminaires - Part: General requirements and tests EN 60598-1

Compliant with relevant EU directives (when correctly installed in the luminaire).

For instructions on how to mount the sensor to the housing and fix the housing to the ceiling please refer to separate Installation guide [Doc. 7860429] which is available on the product website's download and links section.